



WFE2B19XAUS

60CM 14 PLACE FREESTANDING DISHWASHER







FEATURES & BENEFITS



START DELAY

This feature allows you to delay the start time of the program by 2, 4 or 8 hours.



TABLET

This setting allows you to optimize the performance of the program according to the type of detergent used.



EXPRESS 30'

Program to be used for lightly-soiled dishes with no dried food residues.



SOAK

Crockery to be washed later. No detergent to be used with this program.



HALF LOAD

If there are not many dishes to be washed, a half load cycle may be used in order to save water, electricity and detergent.



DRAIN OUT

This feature allows you to stop and cancel an active cycle. The active program will be stopped and the water in the dishwasher will be drained out.

TECHNICAL SPECIFICATIONS

MAIN COLOUR FINISH	Finger Resistant Stainless Steel
DIMENSIONS	W 600mm x H 850mm x D 600mm
CAPACITY	14 Place
DISPLAY	LED
BASKETS	2
PROGRAMS (5)	Eco Intensive Normal Express 30' Soak
FEATURES	Delay Half Load Tablet Drain out
WATER CONNECTION	Hot or Cold
SAFETY	Overflow Protection
TIMER	Delay 8 Hours
NOISE	49 (dBA)
WATER USAGE	12.5L
WATER RATING	4.5 stars
ENERGY RATING	3 stars
NET WEIGHT	47 Kg
WARRANTY	Five years parts and labour
COUNTRY OF ORIGIN	Europe