







# 60CM 4-ZONE CERAMIC HOB WITH TRIPLE ZONE



### **FEATURES & BENEFITS**



#### TRIPLE ZONE

Extended zones can provide a larger cooking area and additional heat to fit for different sizes of cooking pan



### STOP & GO

Suspend the cooking process if you're interrupted then re-start again at the same temperature in an instant with the Stop & Go function.



#### **BLACK CERAMIC GLASS**

A completely smooth cooking surface makes the cooktop extremely easy to clean with just a wipe.



#### CHILD LOCK

Featuring a Child Lock function to prevent toddlers and children from accidentally using the hob.



#### RESIDUAL HEAT INDICATOR

As an added safety precaution, all Whirlpool ceramic hobs have residual heat indicators on each zone to alert you when a zone is still hot.



### WARRANTY


Guarantees peace of mind and value for money knowing that any product fault or defect is covered by full replacement parts and/or a service call to ensure the product works as described.

## **TECHNICAL SPECIFICATIONS**


TYPE	60cm Built-in Ceramic Hob
COOKING ZONES	4
COLOR / FINISH	Black Ceramic Glass
CONTROL	Touch Control
LOCATION OF CONTROL PANEL	Front
PRODUCT NET WEIGHT	8.24kg
PRODUCT DIMENSION	W 590mm x H 51mm x D 520mm
CUT-OUT DIMENSION	W 560mm x D 500mm
FUNCTIONS	Triple Zone, Stop & Go Function
FEATURES	Child Lock, Timer, Residual Heat Indicator, Auto Shutdown, Overheat Protection, Overflow Protection
TOTAL POWER	6,500W
LEFT, FRONT ZONE	2,300W/1,500W/700W
LEFT, REAR ZONE	1,200W
RIGHT FRONT ZONE	1,200W
RIGHT REAR ZONE	1,800W
POWER SETTING	9 levels
ENERGY INPUT	Electric
POWER VOLTAGE	220-240V~, or 380-415V 3N~, 50-60Hz
LENGTH OF POWER CORD	110cm (without plug)
PACKAGING DIMENSION	W 635mm x H 113mm x D 568mm
GROSS WEIGHT	9.15kg
COUNTRY OF ORIGIN	Asia
WARRANTY	5 years



## **INSTALLATION GUIDE**



# **CONTROL PANEL**



- 1. On/Off button
- Cooking level selected Zone selection indicator
- Cooking zone selection button
- Special function icon
- Timer indicators active for the selected zone
- Cooking time indicator
- Timer activation button
- Power and cooking time adjustment buttons
  Indicator light function active
  6<sup>th</sup> Sense button/Key lock button 3 seconds